LED Wall Reading Light Instruction Leaflet



WL3030



Read this instruction carefully before commencing installation and keep it for future reference. Always switch off the mains before installation or maintenance. Keep the product far from heat sources and in a well ventilated area. The installation or maintenance should be carried out by a qualified electrician.

The light source contained in this luminaire shall only be replaced by the manufacturer or his service agent or a similar qualified person. A 42 53 / Cutout: 120*35mm rzzał 5-25mm 50 02 03 01 A OFF WLxxxx / 7xx mm 000 Please refer to cutout label on the product. Ś 61 AC220-240V 50/60Hz 04 06 05



